Audio/Video Rack

Rack Power – leave on!

Video Source Selector

Audio Source Control

CD/Audio Player

Blu-Ray/DVD Player

Classroom Computer

Computer Optical Drive

Computer Power Button

Remote control storage drawer

Do not remove from classroom

External Connections

Ethernet for connecting external devices to the network

Audio plug for connecting external audio devices (Aux knob)

HDMI plug for connecting external laptops
(HDMI button/Video knob)

VGA plug for connecting external laptops
(VGA button)

Do not remove from classroom

DePaul University
SCHOOL OF MUSIC

Video Source Selector

The video source selector panel allows you to switch between the different video sources in the audio/visual rack.

Macintosh

External HDMI Connection

HDMI

PC

Oppo Blu-Ray Player

External VGA

VGA

DVD

Document Camera

DOC

Projector Power

OFF

ON

Aurora

Do not remove from classroom

Audio Source Control

The audio source control panel allows you to control the audio volume between the different audio/video sources in the rack.

Computer audio level/
Blu-ray audio level

CD Player audio level/
Digital audio player level

External Source
audio level

Master
Volume

VIDEO   CD   AUX   BASS   TREBLE   MASTER

SHURE SCM262 stereo mixer   POWER

In case of audio issues with the computer or laptop, please check that:
- Volume is up on computer or laptop
- Audio is not muted on computer or laptop

All audio sources are available simultaneously! You can listen to a CD or an external device while showing a score using the document camera.

Do not remove from classroom